


Assembly Instruction

MERRYFAIR®




Kopi-0

models: 48★ B3 A00 J (3 seat)

48★ B4 A00 J (4 seat)

48★ B5 A00 J (5 seat)






Assembly Instruction

MERRYFAIR®

Kopi-0

model: 48* NA A00 AK





Assembly
Instruction

MERRYFAIR®

Kopi-0

model: 48* NA A00 H





Assembly Instruction

MERRYFAIR®


Kopi-0

model: 48* NA A00 H4




Assembly Instruction

MERRYFAIR®



Kopi-0

model: 48★ NA A00 HH






Assembly
Instruction

MERRYFAIR®

Kopi-0

model: 48* NA A00 Y






Assembly
Instruction

MERRYFAIR®

Kopi-0

model: 48* NA A00 Z





Assembly
Instruction



MERRYFAIR®

Kopi-0

model: 48* NA WT1 H



Assembly Instruction



User Instructions

- A** *Seat Height Adjustable*
Flip up lever on right-side to raise or lower seat. Adjust such that your feet are adequately supported on floor.

Kopi-0

model: 48★ HB A00 M3

