





Assembly Instruction

MERRYFAIR®






Silver Surf

models: 450(B2-B6) A00 AG
460(B2-B6) A00 AG



Assembly Instruction




MERRYFAIR®



Silver Surf









model: A39

For reference:






Assembly Instruction

MERRYFAIR®




Silver Surf

model: MSC471 BACK



Assembly Instruction




MERRYFAIR®



Silver Surf


model: MSC471 SEAT

For reference:





Assembly Instruction

MERRYFAIR®



Silver Surf POWER OUTLET



Silver Surf

models: 45(1-9) (B2-B6) A39 AG
46(1-9) (B2-B6) A39 AG
47(1-9) (B2-B6) A39 AG

