


# Assembly Instruction




# ANGGUN


Models  
1199 YP A78 V  
1198 YP A78 V  
1199 YP A80 V  
1198 YP A80 V

# User Instructions

- A Seat Height Adjustable**  
Flip up lever on right-side to raise or lower seat. Adjust such that your feet are adequately supported on floor.
- B Multi-Position Tilt Lock**  
Recline to desired position, and turn the round knob anti-clockwise to lock. Turn the knob clockwise to release tilt-lock.
- C Seat Angle Lock**  
Flip up lever on left-side for forward seat tilt and this cater for intensive upright sitting tasks. Flip down lever for normal seat angle.
- D Lumbar Height Adjustment**  
Slide the lumbar support up or down for desired lumbar position.
- E Armrest Height**  
Press the button and raise or lower the armrest. Adjust height to adequately support elbows to take strain off shoulders.
- F Armpad Angle**  
Grasp armpads and rotate them inwards or outwards to adjust elbow support to suite specific tasks. An inward position works during keyboard use, while an outward position is recommended during mousing.
- G Armrest Depth**  
Grasp armpads and push them forwards and backwards to suite your arm support.
- H Seat Depth Adjustment**  
Pull the lever under the right-side of the seat to adjust fore and aft position.
- I Tilt Tension Control**  
Pull out the knob at the right side, turn knob clockwise to provide a stronger tilt tension, and vise versa. Adjust such that minimum effort is required to push back when recline.
- J Headrest Height** (Only applicable for 1199 model)  
Adjust height by holding both sides of headrest and pull up or down to your desired height.



## Assembly Instruction



## ANGGUN


Models

1191 NA A78 B


1191 NA A80 B

## User Instructions

- A Lumbar Height Adjustment**  
Slide the lumbar support up or down for desired lumbar position.
- B Armrest Height**  
Press the button and raise or lower the armrest. Adjust height to adequately support elbows to take strain off shoulders.
- C Armpad Angle**  
Grasp armpads and rotate them inwards or outwards to adjust elbow support to suite specific tasks. An inward position works during keyboard use, while an outward position is recommended during mousing.
- D Armrest Depth**  
Grasp armpads and push them forwards and backwards to suite your arm support.




# Assembly Instruction




# User Instructions

## ANGGUN Models 1191 NA A15 B

- A** **Lumbar Height Adjustment**  
Slide the lumbar support up or down for desired lumbar position.



# Assembly Instruction



# ANGGUN

## Models

1199 YM A78 V

1198 YM A78 V

1199 YM A80 V

1198 YM A80 V

# User Instructions

- A Seat Height Adjustable**  
Flip up lever on right-side to raise or lower seat. Adjust such that your feet are adequately supported on floor.
- B Multi-Position Tilt Lock**  
Recline to desired position, and flip down lever to lock. Flip up lever to release tilt-lock.
- C Lumbar Height Adjustment**  
Slide the lumbar support up or down for desired lumbar position.
- D Armrest Height**  
Press the button and raise or lower the armrest. Adjust height to adequately support elbows to take strain off shoulders.
- E Armpad Angle**  
Grasp armpads and rotate them inwards or outwards to adjust elbow support to suite specific tasks. An inward position works during keyboard use, while an outward position is recommended during mousing.
- F Armrest Depth**  
Grasp armpads and push them forwards and backwards to suite your arm support.
- G Seat Depth Adjustment**  
Pull the lever under the right-side of the seat to adjust fore and aft position.
- H Headrest Height** (Only applicable for 1199 model)  
Adjust height by holding both sides of headrest and pull up or down to your desired height.

